
SEV 8 23IME





FOR FIELD ASSISTANCE PLEASE CALL +1-213-255-2060 #4

- Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker.
- All servicing or relamping must be performed by qualified service personnel.
- Product must be grounded to avoid potential electric shock or other potential hazard.
- Product must be installed at locations and heights, in a manner consistent with its intended use, and in compliance with electrical code and local codes.


SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE




meteor-lighting.com

INSTALLATION GUIDE REV 8 PRIME RETROFIT - GOOF RING


METE^OR



Place fixture into ceiling aperture and secure the bracket.



Slip goof ring over reflector.



Install reflector and goof ring into the fixture.