
VELAS





FOR FIELD ASSISTANCE PLEASE CALL +1-213-255-2060 #4

- Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker.
- All servicing or relamping must be performed by qualified service personnel.
- Product must be grounded to avoid potential electric shock or other potential hazard.
- Product must be installed at locations and heights, in a manner consistent with its intended use, and in compliance with electrical code and local codes.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE



meteor-lighting.com

INSTALLATION GUIDE

VELA 5 SHROUD INSTALLATION

METE^OR



Bring shroud to the fixture level and align it to the indicated openings. Fasten shroud in place with three phillips screws.

*Clean gloves must be worn to avoid dirt and fingerprints when installing the shroud and diffuser



Clean the interior and exterior surface using a soft rag with water.

INSTALLATION GUIDE

VELA 5 CONICAL LENS INSTALLATION

METE^OR



Clean the interior and exterior surface using a soft rag with water.



When specifying the conical lens accessory. Cover the shroud with the conical lens plate and fasten in place using the provided metal band.

 meteor-lighting.com
 1860 S Carlos Ave, Ontario, California 91761 E: tech@meteor-lighting.com T: 213-255-2060

 Meteor Lighting reserves the right to make changes to this product for design and development improvements at any time without prior notice, and such modification shall be effective immediately. ©Meteor Illumination Technologies, Inc.

 07-16-2024